# MI DEQ & RETAP Pollution Prevention (P2) Training

### Metal Fabrication: Cutting & Stamping

Cam Metcalf, Executive Director Richard Meisenhelder, P2 Specialist Lori Hoetker, Technical Coordinator Kentucky Pollution Prevention Center (KPPC)



## Types of Metal Fabrication Wastes

- **□** Corrosive
- **■** Waste Water
- Used Oils
- **□** Solvents
- **□**Sludges
- **■**Metalworking Fluids
- **□Solid Wastes**

#### **Corrosive Wastes**

- **□Spent pickling acids**
- **□Spent alkaline cleaning solutions**
- □Discarded molten-bath, alkali-salt cleaning mixtures

### Sludges

- ☐ Treatment of electroplating, heat-treating or anodizing waste water
- **■** Paint-related sludges
- **□** Grinding sludge
- ☐ Clean-out solvent or aqueous systems, sumps or grease traps
- **Distillation still bottoms**

#### Waste Water

- **☐** Electroplating systems
- **☐** Anodizing systems
- ☐ Parts cleaning systems (acidic or alkaline)
- **■** Water-curtain spray booths
- □ Paint stripping systems
- ☐ Floor washing (Maintenance & Housekeeping)
- ☐ Cooling systems & Boiler blow-down
- **Domestic sewage**

#### Metalworking Fluids

- Cutting oils: Fortified petroleum oils
- **□**Soluble oils:
  - 30 90% oil
- ☐ Semi-synthetic fluids:
  - 1 30% oil
- Synthetic fluids: 0 1% oil

#### **Used Oils**

- **■** Metalworking fluids
- ☐ Hydraulic oils
- Lubricating oils
- Compressor oils
- Motor oils
- **□** Oil Filters
- Oil-soaked absorbent materials
- **☐ Shop Towels**

#### Solvent Wastes

- □ Degreasing items before Painting or Plating
- □ Removing metalworking fluids
- Cleaning manufacturing equipment
- Cleanup of painting equipment
- **■**Solvent evaporation

## Sources of Solvent Wastes

- **■Vapor degreasers**
- Paint spray booths
- Paint mixing & cleaning stations
- Drying & curing ovens
- ☐ Sinks, tubs & vats used for cleaning parts & dies
- Manual cleaning products: rags, containers, sprayers & aerosol cans

#### Solid Wastes

- **Metal Wastes**
- **☐** Paper Products
- Aerosol cans
- **☐** Fluorescent Tubes
- ☐ Packaging & Shipping wastes:
  - Wooden pallets, crates & boxes
  - ☐ Steel drums, pails, straps & cans
  - Plastic drums, pails, stretch wrap & straps
  - **■** Expanded polystyrene
  - ☐ Aluminum cans

### Metal Cutting & Stamping

- ☐ Key to P2 for both is effective fluid management
- Main types of cutting fluids—pros & cons
- **□What fluids do**
- ☐ Components of a fluid environmental management program
- ☐ Fluid recycling & disposal

#### Metal Cutting & Stamping

Common cutting fluid functions Cool Lubricate Remove fines/cuttings from cutting zone **Corrosion protection (esp. ferrous materials)** Choice of coolant affects tool wear & part quality (surface finish and size). ■ No one type of cutting fluid provides best cooling & lubrication. Generally a tradeoff. Fewer coolants are easier to manage in a shop.

### Types of Fluids Oil-based (100% petroleum)

- ✓ excellent lubricity (cushioning) allows use in severe machining & difficult-to-cut metals
- ✓ good rust protection
- **√**easy maintenance
- **✓** extended sump life
- ✓ resistant to bacterial growth

- ✓ poor heat dissipating qualities
- √ higher fire risk
- **✓** mist generation
- ✓ limited to lowtemperature/low speed & severe cutting operations
- ✓oil on part often requires cleaning

# Types of Fluids Oil-based (60-90% petroleum)

- ✓ improved cooling capabilities
- ✓ good lubrication due to oil & water blending
- ✓ general purpose product for light and medium duty on ferrous & nonferrous metals

- ✓ water increases susceptibility to rusting, bacterial growth & evaporative losses
- ✓ higher maintenance costs
- can be difficult to clean (oily film)

### Types of Fluids Synthetic (0% petroleum)

- ✓ superior cooling & corrosion control
- ✓ suitable for wide range of machining
- ✓ reduced misting & foaming
- ✓ easily separated from workpiece & chips, less dragout & easier cleanup
- **√**long service life

- ✓ moderate to high agitation causes foam & some mist generation
- **√** may emulsify tramp oil
- **√** may form residue
- ✓ easily contaminated by other machining fluids

### Types of Fluids Semi-synthetic (2-30% petroleum)

- ✓ good corrosion control, cooling & lubrication
- ✓ easily separated from workpiece/chips
- **√**long service life
- ✓ suitable for many machining operations

- ✓ moderate to high agitation causes foam & some mist generation
- **√** may emulsify tramp oil
- **√** may form residue
- ✓ easily contaminated by other machining fluids

#### Costs of Poor Fluid Quality

- ☐ Increased machine & tool wear
- ☐ Impaired part quality/increased reject costs
- **☐** Increased machine downtime
- ☐ Increased fluid purchase, mix & disposal costs
- ■Increased labor costs associated with all the above

### Metal Cutting & Stamping P2 Opportunities

- ☐ Use high-quality metalworking fluid
- **■**Select right fluid for job
- Maintain equipment to prevent sump contamination (cleaning sump & machine, gasket, wiper & seal maintenance)
- Proper fluid monitoring & cleaning
- ☐ Assigned fluid control responsibility
- **■**Separate metal & fluid waste

- Commitment from interested parties
  - ☐ Top management (time, money, leadership focus)
  - ☐ Employees ("how-to" input)
  - Vendor (technical know-how on fluid/equipment)
- Defined roles & responsibilities
  - ☐ Initially to gather baseline performance data
  - ☐ Then to <u>sustain</u> monitoring, measurement & maintenance of FMP

- **Establish operational controls** 
  - ☐ Fluid control points: water quality requirements (e.g., water hardness & dissolved solids), water/concentrate ratios, contaminant levels & pH
  - **Work instructions** 
    - ✓ roles & responsibilities, control points & how-to measure, mixing & maintaining fluids, annual cleanout

- Contaminants to watch for...
  - ☐ Tramp oils—leak into sump from other machine parts. Can be any other oils from machine or parts. Can contribute to next problem...
  - Bacterial growth: problematic in watermiscible fluids. Bacteria lower fluid pH, increasing tool/part corrosion & staining, dissolve chips/fines, possibly making fluid hazardous waste come disposal time

- ☐ And how to prevent them...
  - ☐ Tramp oils
    - **✓** Find and fix leaks through proactive preventative maintenance
    - ✓ Remove metal chips/fines (i.e., "yellow-bellied sump sucker")
    - ✓ Skim/centrifuge fluid to remove
  - Bacterial growth
    - **✓** Control water quality (e.g., dissolved minerals)
    - ✓ Maintain proper fluid concentration & pH
    - ✓ Routine maintenance & cleaning of machines, lines, & sumps
    - **✓** Biocide additions
    - **✓** Aeration

- Monitoring & measurement-fluid concentration
  - ☐ Refactometers: measures fluid concentration by sending light through fluid. The more it refracts or bends, the higher the fluid concentration.
  - ☐ Titration: slower but typically more accurate that refractometers for fluid concentration.

    Less affected by contaminants.

- Monitoring & measurement: pH
  - ☐ Litmus paper: quick & inexpensive but accurate to +/- one full pH unit
  - ☐ pH meter: more expensive (\$50-\$200 dollars) but accurate to +/- 0.2 pH units
- Monitoring & measurement: bacteria
  - ☐ Plate counts/dipslide tests—both inexpensive.

    Recommended testing weekly or biweekly especially during program startup

# Components of a Fluid Management Program (FMP): Recordkeeping

Machine Sump Capacity Tupe of Fluid Used					FLUID MANAGEMENT LOG  Initial Parameter Readings for Fresh Fluid  Concentration Reading =  pH =									
					System Inspection Observations					Fluid Adjustments				
Date	Fluid Concentration	рН	Bological Monitoring		Tranqu	Excessive			Concentrate		Other	Fluid Changed Out	Problems / General Comments	
		J										Y or N		
												YorN		
												YorN		
												YorN		
												YorN		
								1				YorN		
		1				- 5					-	YorN		
											-	YorN		
												YorN		
												YorN		
												YorN		
									1			YorN		
												Y or N		
												YorN		
							- 0					YorN		
									8			YorN		
												YorN		
												Y or N		
												YorN		
												YorN		
												YorN		
												Y or N		
7			-						-			Y or N		
								-				YorN		

#### Fluid Cleaning & Recycling

- **□**Skimmers
- Coalescers
- Centrifuging
- **□** Hydrocycloning
- **□** Filtration
- **■** Pasteurization
- **□**Flotration

# "Cutting-Edge" P2 Opportunities

- ☐ Air as fluid replacing cutting oils
- **□**Laser-cutting
- Water-jet cutting
- ☐ Plasma-arc welding
- □ CNC (computer numerical control) machining

#### **Additional Resources**

- North Carolina Waste Reduction Resource Center, Waste Reduction for Metal Machining <a href="http://wrrc.p2pays.org/industry/metalmach.htm">http://wrrc.p2pays.org/industry/metalmach.htm</a>
- Cutting Fluid Management for Small Machining Operations: A Practical Pollution Prevention Guide, Iowa Waste Reduction Center, University of Northern Iowa, 1996
- ☐ EPA Guide to Pollution Prevention: The Fabricated Metal Products Industry, EPA/625/7-90/006, July 1990

# MI DEQ & RETAP Pollution Prevention (P2) Training

Next Steps: Assess Cutting & Stamping Operations & Implement a FMP!

Cam Metcalf, Executive Director Richard Meisenhelder, P2 Specialist Lori Hoetker, Technical Coordinator Kentucky Pollution Prevention Center (KPPC)

